

# SOFTTEL

## SFT358X 4-in-1 IRD User's Manual



*Web-NMS Version: 1.03*

*Software: 1.00*

*Hardware: 0.40*

---

**Hangzhou Softel Optic Corp. Ltd.**

# About This Manual

## Intended Audience

This user manual has been written to help people who have to use, to integrate and to install the product. Some chapters require some prerequisite knowledge in electronics and especially in broadcast technologies and standards.

## Disclaimer

No part of this document may be reproduced in any form without the written permission of the copyright owner.

The contents of this document are subject to revision without notice due to continued progress in methodology, design and manufacturing. SOFTEL shall have no liability for any error or damage of any kind resulting from the use of this document.

## Copy Warning

This document includes some confidential information. Its usage is limited to the owners of the product that it is relevant to. It cannot be copied, modified, or translated in another language without prior written authorization from SOFTEL.

# DIRECTORY

<b>Chapter 1 Product Outline.....</b>	<b>1</b>
1.1 Outline.....	1
1.2 Features.....	1
1.3 Specifications.....	1
1.4 Principle Chart.....	2
1.5 Appearance and description.....	3
<b>Chapter 2 Installation Guide.....</b>	<b>4</b>
2.1 Acquisition Check.....	4
2.2 Installation Preparation.....	4
2.3 Wire's Connection.....	6
2.4 Signal Cable Connection.....	6
<b>Chapter 3 Operation.....</b>	<b>8</b>
3.1 LCD Menu Class Tree.....	8
3.2 General Setting.....	11
<b>Chapter 4 Web-based NMS Management.....</b>	<b>22</b>
4.1 login.....	22
4.2 Operation.....	22
<b>Chapter 5 Troubleshooting.....</b>	<b>39</b>
<b>Chapter 6 Packing List.....</b>	<b>40</b>

# Chapter 1 Product Outline

## 1.1 Outline

SFT358X IRD is SOFTEL's new design which integrates demodulation (DVB-C, T/T2, S/S2 optional), de-scrambler and multiplexing in one case to convert RF signals into TS output.

It is a 1-U case which supports 4 tuner inputs, 1 ASI and 4 IP inputs. The 4 CAMs/CIs accompanied can descramble the programs input from encrypted RF, ASI and IP. The CAM requires NO unsightly external power cords, cables, or additional remote control device. BISS function is also embedded to descramble programs.

To meet customers' various requirements, SFT358X is also designed to de-mux programs from any input, and output TS over 48 SPTS.

## 1.2 Features

- **4 Tuner inputs (DVB-C, T/T2, S/S2 Optional)**
- **1 ASI & 4 IP (UDP) input for de-mux**
- **One CAM can decrypt multiple programs from Tuners/ASI/IP**
- **Support BISS descrambling(Up to 120 Mbps)**
- **IP (48 SPTS) over UDP and RTP/RTSP output;**
- **4 groups of independent ASI out for tuner/IP passthrough (one-to-one)**
- **Support maximum 128 PID mapping per input**
- **Support Diseqc function**
- **LCD display, Remote control and Firmware, web NMS management**
- **Updates via web**
- **High quality and breakthrough price**

## 1.3 Specifications

**Input**

4x RF (DVB-C, T/T2, S/S2 optional), F type  
 1xASI input for de-mux, BNC interface  
 4xIP input for de-mux (UDP)

**Tuner Section****DVB-C**

Standard J.83A(DVB-C), J.83B, J.83C  
 Input Frequency 47 MHz~860 MHz  
 Constellation 16/32/64/128/256 QAM

**DVB-T/T2**

Input Frequency 44MHz ~1002 MHz  
 Bandwidth 6/7/8 M

**DVB-S**

Input Frequency 950-2150MHz  
 Symbol rate 1~45Mbauds  
 Signal Strength - 65- -25dBm  
 Constellation 1/2, 2/3, 3/4, 5/6, 7/8 QPSK

**DVB-S2**

Input Frequency 950-2150MHz  
 Symbol rate QPSK/8PSK 1~45Mbauds  
 Code rate 1/2, 3/5, 2/3, 3/4, 4/5, 5/6, 8/9, 9/10  
 Constellation QPSK, 8PSK

**Output**


IP 48\*SPTS over UDP, RTP/RTSP.  
 1000M Base-T Ethernet interface (unicast/multicast)  
 4\*MPTS over UDP, RTP/RTSP.  
 1000M Base-T Ethernet interface, for RF in passthrough (one-to-one)  
 ASI 4 groups BNC interface

**System**

Local interface LCD + control buttons  
 Remote management Web NMS Management  
 Language English

**General**

Power supply AC 100V~240V  
 Dimensions 482\*400\*44.5mm  
 Weight 3 kgs  
 Operation temperature 0~45°C

**1.4 Principle Chart**

Choose 4 channels from the 9 inputs to descramble  
 CI 1 & 2 are designed to descramble tuner 1/2, ASI or IP 1-4.  
 CI 3 & 4 are designed to descramble tuner 3/4, ASI or IP 1-4.  
 ASI out and MPTS IP out are for passthrough RF/IP inputs one to one.

## 1.5 Appearance and description

Front Panel Illustration:



1	LCD Display
2	Indicators Area (Lock 1-4: they light up when the tuner signal are properly connected. Descram 1-4: they light up when the CI cards are properly inserted).
3	Up/Down/Left/Right Buttons
	Enter Key for confirmation
	Menu Key for backward
	Lock Key

Rear Panel Illustration



1	CAM/CI Slots 1 & 2 (Applied to descramble tuner 1 & 2, ASI input and IP input 1 to 4)
2	Tuner Input 1 & 2
3	CAM/CI Slots 3 & 4 (Applied to descramble tuner 3 & 4, ASI input and IP input 1 to 4)
4	Tuner Input 3 & 4
5	ASI output groups 1-4
6	ASI input port for de-mux
7	NMS Port (connect to PC for device management)
8	DATA Port (for IP stream input & output, 1000M)
9	Power switch/Fuse/Socket/Grounding Wire

## Chapter 2 Installation Guide

### 2.1 Acquisition Check

When user opens the package of the device, it is necessary to check items according to packing list. Normally it should include the following items:

- |                                   |      |
|-----------------------------------|------|
| ● SFT358X 4-in-1 IRD              | 1pcs |
| ● User's Manual                   | 1pcs |
| ● Tuner Cables (for loop through) | 2pcs |
| ● Power Cord                      | 1pcs |

If any item is missing or mismatching with the list above, please contact our company.


### 2.2 Installation Preparation

When users install device, please follow the below steps. The details of installation will be described at the rest part of this chapter. Users can also refer rear panel chart during the installation.

The main content of this chapter including:

- Checking the possible device missing or damage during the transportation
- Preparing relevant environment for installation
- Installing modulator
- Connecting signal cables
- Connecting communication port (if it is necessary)

#### 2.2.1 Device's Installation Flow Chart Illustrated as following:



#### 2.2.2 Environment Requirement

Item	Requirement
Machine Hall Space	When user installs machine frame array in one machine hall, the distance between 2 rows of machine frames should be 1.2~1.5m and the distance against wall should be no less than 0.8m.
Machine Hall Floor	Electric Isolation, Dust Free Volume resistivity of ground anti-static material: $1 \times 10^7 \sim 1 \times 10^{10} \Omega$ , Grounding current limiting resistance: 1M (Floor bearing should be greater than $450 \text{Kg/m}^2$ )
Environment Temperature	5~40°C(sustainable ), 0~45°C(short time), installing air-conditioning is recommended
Relative Humidity	20%~80% sustainable 10%~90% short time
Pressure	86~105KPa
Door & Window	Installing rubber strip for sealing door-gaps and dual level glasses for window
Wall	It can be covered with wallpaper, or brightness less paint.
Fire Protection	Fire alarm system and extinguisher
Power	Requiring device power, air-conditioning power and lighting power are independent to each other. Device power requires AC power 100-240V 50-60Hz. Please carefully check before running.

### 2.2.3 Grounding Requirement

- All function modules' good grounding is the basis of reliability and stability of devices. Also, they are the most important guarantee of lightning arresting and interference rejection. Therefore, the system must follow this rule.
- Coaxial cables outer conductor and isolation layer should keep proper electric conducting with the metal housing of device.
- Grounding conductor must adopt copper conductor in order to reduce high frequency impedance, and the grounding wire must be as thick and short as possible.
- Users should make sure the 2 ends of grounding wire well electric conducted and be antirust.



- It is prohibited to use any other device as part of grounding electric circuit
- The area of the conduction between grounding wire and device's frame should be no less than 25mm<sup>2</sup>.

#### 2.2.4 Frame Grounding

All the machine frames should be connected with protective copper strip. The grounding wire should be as short as possible and avoid circling. The area of the conduction between grounding wire and grounding strip should be no less than 25mm<sup>2</sup>.

#### 2.2.5 Device Grounding

Connecting the device's grounding rod to frame's grounding pole with copper wire.

### 2.3 Wire's Connection

The grounding wire conductive screw is located at the right end of rear panel, and the power switch, fuse, power supply socket is just beside ,whose order goes like this, power switch is on the left ,power supply socket is on the right and the fuse is just between them.

- Connecting Power Cord

User can insert one end into power supply socket, while insert the other end to AC power.

- Connecting Grounding Wire

When the device solely connects to protective ground, it should adopt independent way, say, share the same ground with other devices. When the device adopts united way, the grounding resistance should be smaller than 1Ω.

---

**⚠ Caution:**

**Before connecting power cord to SFT358X IRD, user should set the power switch to "OFF".**

### 2.4 Signal Cable Connection

The signal connections include the connection of input signal cable and the connection of output signal cable. The details are as follows:

#### 2.4.1 SFT358X 4-in-1 IRD Cables Illustration:

- **IP Input/output Cable Illustration:**



- **Tuner Cable Illustration:**



- **ASI Input/output Cable Illustration:**



## Chapter 3 Operation

The front panel of SFT358X 4-in-1 IRD is the user-operating interface and the equipment can be conveniently operated and managed according to the procedures displayed on the LCD:

### **Keyboard Function Description:**

**LEFT/RIGHT:** Choose and set the parameters.

**UP/DOWN:** Modify activated parameter or paging up/down when parameter is inactivated.


**ENTER:** Activate the parameters which need modifications, or confirm the change after modification.


**MENU:** Cancel current entered value, resume previous setting; Return to previous menu.


**LOCK:** Lock the screen/cancel the lock state. After pressing the lock key, the LCD will display the current configuring state.

### **3.1 LCD Menu Structure**

*(See next page :)*









## 3.2 General Setting

Switch on the device and after a few seconds' initialization, it presents start-up pictures as below:



- **4 in 1 IRD:** Device's name
- **Bitrate: xx.xxx Mbps** indicates the current output bitrate.

Press LOCK key on the front panel to enter the main menu. The LCD will display the following pages where user can configure the parameters for the device:



User could do all the settings according to the 7 directions displayed on the LCD. User can press UP/DOWN and RIGHT/LEFT buttons to specify menu item, and then press ENTER to enter the submenus as below:

### 3.2.1 Status

**Alarm:** The alarm indicator will turn on if there is no signal inputting or outputting bit rate overflows. User then can enter this menu to check the error type. Otherwise it shows the 'system is normal'.

**Alarm**  
**System is normal**

**Uptime:** It displays the working time duration of the device. It times upon power on.

**Uptime**  
**1 Day(s) 03:30:02**

### 3.2.2 Input Sets

SFT358X supports 4 tuners input, 1 ASI input and 4 IP stream input. Users can enter 'Input Sets' to configure the tuner/ASI/IP parameters to receive the transport streams and select programs to output via IP (SPTS) packages. It displays as below:

▶ **2.1 Tuner DVBS/S2 2.2 Tuner DVBS/S2**  
**2.3 Tuner DVBS/S2 2.4 Tuner DVBS/S2**

▶ **2.5 ASI 2.6 IP**  
**2.7 IP 2.8 IP**

▶ **2.9 IP**


#### ➤ **Tuner DVB-S/S2 (Submenus 2.1 – 2.4)**

Press ENTER key to enter '2.1 Tuner DVBS/S2' (or 2.2/2.3/2.4) to configure the corresponding tuner input according to rear panel. It displays as below:

▶ **2.1.1Tuner Para 2.1.2Mux Prog**


Tuner Parameters:


Users can enter this menu to configure the tuner parameters separately to receive the tuner programs.



Mux Program:

Users can parse the Tuner input program list and select programs to out in this menu.

 **NOTE:** Multiplexed programs can only be output through IP (48 SPTS).



'1/7' represents there are all 7 programs in the list and 1 program has been selected to mux out through ASI.

### ➤ ASI (Submenus 2.5)

Users can parse ASI input programs and select program(s) to output under this menu. The operating method is same with what explained above.





<b>2.5.1 TS Lock</b>	<b>2.5.2 Parse Program</b>
<b>2.5.3 Select Program</b>	

### ➤ IP (Submenus 2.6 – 2.9)

Press ENTER key to enter '2.6 IP', it displays as below:



<b>2.6.1 IP Config</b>	<b>2.6.2 Mux Program</b>
------------------------	--------------------------

#### IP Config:

Users can enter this menu to configure IP parameters according to the IP source to receive the IP programs.



<b>Input IP</b>	
<b>Input Port</b>	
<b>Multicast</b>	
<b>IGMP Snooping</b>	
<b>Service IP</b>	

→ Off, V2 and V3 Optional

#### Mux Program:

Users can parse the IP input program list and select programs to output in this menu. The operating method is same with what explained above.



<b>2.5.1 TS Lock</b>	<b>2.5.2 Parse Program</b>
<b>2.5.3 Select Program</b>	


### 3.2.3 CI Card

SFT358X IRD supports 4 CI cards (Card A, B, C and D) to descramble encrypted programs from RF, ASI or IP. Users can press ENTER key to enter '3 CI Card' to configure the 4 cards respectively.



<b>3.1 Card A</b>	<b>3.2 Card B</b>
<b>3.3 Card C</b>	<b>3.4 Card D</b>

Press ENTER key to enter Card A (or Card B/C/D):



<b>3.1.1 Max Bitrate</b>	<b>3.1.2 Input TS Mode</b>
<b>3.1.3 Card Error</b>	<b>3.1.4 Parse Program</b>



<b>3.1.5 Descra Prog</b>	<b>3.1.6 Rom Version</b>
<b>3.1.7 Card Status</b>	<b>3.1.8 Descramble Error</b>


### ➤ Max Bit rate

CI Max Bitrate options range from 48-108Mbps. Move the triangle to select a value as principle: Actual Input Bitrate ≤ Max Bitrate ≤ CI Max decrypting capacity

**Max Bitrate**  
▶ 48 Mbps

### ➤ Input TS Mode

SFT358X has 9 signal sources: Tuner 1-4, ASI, and IP1-4. One CI card can applied to descramble one channel input signal from the 9 signal sources. 'Skip CI card' means to skip the card which is used for FTA stream.

 **NOTE:** Card A & B are designed to descramble tuner 1 & 2, ASI input and IP input 1 to 4, while card C & D A are designed to descramble tuner 3 & 4, ASI input and IP input 1 to 4.

**Input TS Mode**  
▶ Skip CI Card  
Tuner 1  
Tuner 2  
ASI  
IP 1  
IP 2  
IP 3  
IP 4

### ➤ Card Error Check

Users can decide whether to enable or disable the card error check function in this menu.

**Card Error Check**  
▶ Enable

### ➤ Parse Program

Users can read the quantity of programs parsed from the de-scrambled channel.

**Searching Program**  
Get 8 Programs

### ➤ Descramble Program

Users can select program(s) from the searched out programs to descramble. The quantity to be descrambled depends on the CAM/CI performance you apply to.

▶ 1 CETV 1	✓
2 CCTV 4A	✗

### ➤ Rom Version/Card Status/Descramble Error

Users can read the other info about the CI card in the following menus.

**Rom Version**  
4.2.4.0

**Card Status**  
Normal

**Dscramble Error**  
Normal

## 3.2.4 BISS Descrambling

SFT358X IRD supports also BISS to descramble encrypted programs from RF, ASI or IP.

Users can enter '4 BISS Descrambling' to configure the 4 BISS respectively.


▶ **CI Card**  
BISS A  
BISS B  
BISS C  
BISS D

Press ENTER key to enter BISS A (or BISS B/C/D):

▶ **BISS A**  
Input TS Mode  
Descrambler Key  
SK  
Word Mode  
Burned Key  
TS Lock  
Parse Program  
Desc Program

### ➤ Input TS Mode

SFT358X has 9 signal sources: Tuner 1-4, ASI, and IP 1-4. One BISS can be applied to descramble one channel input signal from the 9 signal sources. 'Skip BISS' means to skip the card which is used for FTA stream.

 **NOTE:** BISS A & B are designed to descramble tuner 1 & 2, ASI input and IP input, while BISS C & D A are designed to descramble tuner 3 & 4, ASI input and IP input.

**Input TS Mode (1/5)**  
 ► **Skip BISS**  
**Tuner 1**  
**Tuner 2**  
**ASI**  
**IP1**  
**IP2**  
**IP3**  
**IP4**

### ➤ Descrambler Key/SK/Word Mode/Burned Key

Users need to input keys to descramble programs as per the BISS scrambling side which usually is DVB-S/S2 modulator.

The descrambling principle is as following chart:

Modulating Side (BISS SCR)	Receiving Side (BISS DESCR)	Digit (0x----)
Mode 1+SW Data	Mode 1+Descrambler Key	12
Mode E+ESW Data + Device	Mode E + Descrambler Key + Burned Key	16
Mode E+ESW Data + Input ID	Mode E + Descrambler Key + SK	14

### ➤ TS Lock

Users can read the real-time bitrate of the corresponding channel.

**TS Locked**  
**Bitrate: 34.662 Mbps**

### ➤ Parse Program

Users can read the quantity of programs parsed from the de-scrambled channel.

**Searching Program**  
**Get 7 Programs**

### ➤ Descramble Program

Users can select program(s) from the searched out programs to descramble.

▶ **1 CETV 1**      ✓  
**2 CCTV 4A**      X

## 3.2.4 TS Config

Users can press ENTER key to enter '4 TS Config' to configure the parameters of TS output through ASI port groups. Submenus under TS Config are as follows:

▶ **4.1 TS output bitrate 4.2 ASI 1 out select**  
**4.3 ASI 1 out bitrate 4.4 ASI 2 out select**


▶ **4.5 ASI 2 out bitrate 4.6 ASI 3 out select**  
**4.7 ASI 3 out bitrate 4.8 ASI 4 out select**

▶ **4.9 ASI 4 out bitrate 4.10 TSID**  
**4.11 ONID**

**TS Output bit-rate:** Users can set TS output bit rate in this menu.

**TS output bit rate**  
**054 Mbps**

**ASI X out select:** SFT358X is equipped with 4 pairs of ASI out ports. Each pair can transfer one channel of **tuner** or one channel of **IP** content of corresponding channel. For instance, user can select content from “tuner 1” or “IP 1” to output through “ASI 1”.



**ASI X out bit-rate:** Users can set TS output bit rate for the corresponding channel.

**ASI X out bit rate**  
**054 Mbps**

**TS ID:** Users can set TS ID in this menu.

**TS ID**  
**00001**

**ON ID:** Users can set ON ID (original network ID) in this menu.

**ON ID**  
**00001**

### 3.2.5 IP Stream

SFT358X IRD supports 48 SPTS over IP (UDP, RTP/RTSP) output. Users can set the IP out parameters in this menu..

5.1 -5.4: To configure the general parameters for the IP out

▶ **5.1 Service IP**  
**5.3 Gateway**

**5.2 Subnet Mask**  
**5.4 Output Protocol**

▶ **5.5 SPTS 1**  
**5.7 SPTS 3**

**5.6 SPTS 2**  
**5.8 SPTS 4**

5.5 -5.52: Enter each sub-menu to configure the SPTS out parameters.

▶ **5.49 SPTS 45**  
**5.51 SPTS 47**

**5.50 SPTS 46**  
**5.52 SPTS 48**

### 3.2.6 Network

Users can set network parameters in this menu. Enter 'Network' submenus to separately set corresponding parameters.

▶ **6.1 NMS IP**  
**6.3 Gateway**

**6.2 Subnet Mask**  
**6.4 MAC Address**

▶ **6.5 Web NMS Port**

**6.6 Reset Password**



**NMS IP**  
192.168.000.136 → The IP address for connecting the device to PC

**Subnet Mask**  
255.255.255.000

**Gateway**  
192.168.000.001

**MAC Address**  
 201012345678

**Web NMS Port**  
00080

**Reset Password?**  
 Yes ► NO

### 3.2.7 System

Users can set the system parameters in this menu. Enter 'System' submenus to separately set corresponding parameters.

► 7.1 Save Config    7.2 Load Saved CFG  
 7.3 Factory Reset    7.4 LCD Time-out

► 7.5 Key Password    7.6 Lock Keyboard  
 7.7 Product ID    7.8 Language


► 7.9 Version

↓

**Save Configuration?**  
 Yes    ► No → Choose yes to save settings. and press ENTER to confirm

Choose yes to restore the device into the last saved configuration. ← **Load Saved CFG?**  
 Yes    ► No

**Reset All Sets?**  
 Yes    ► No





## Chapter 4 Web-based NMS Management

In addition to using front buttons to control the device, users can also control and set the configuration with the web Brower in the PC.

### 4.1 login

The default IP address of this device is 192.168.0.136. (We can modify the IP through the front panel.)

Connect the PC (Personal Computer) and the device with net cable, and use ping command to confirm they are on the same network segment.

I.G. the PC IP address is 192.168.99.252, we then change the device IP to 192.168.99.xxx (xxx can be 1 to 254 except 252 to avoid IP conflict).

Use web browser to connect the device with PC by inputting the device's IP address in the browser's address bar and press Enter.

It will display the Login interface as Figure-1. Input the Username and Password (Both the default Username and Password are "admin".) and then click "LOGIN" to start the device setting.




Figure-1

### 4.2 Operation

#### Summary:

When we confirm the login, it displays the WELCOME interface as Figure-2 where users

can have an overview of the device's system information and working status.




Figure-2

### Parameters → Input 1/2/3/4 (Tuner Input 1-4):

From the menu on left side of the webpage, clicking “Input 1” (or “Input 2/3/4”), it displays the interface where users can configure the 4 Tuner input parameters separately. (Figure-3)




Figure-3

**Parameters → Input 5 (ASI Input):**

“Input 5” refers to the ASI source, this page is not applicable as it does not need to configure ASI signal. (Figure-4)




Figure-4

### Parameters → Input 6/7/8/9 (IP Input 1-4):

From the menu on left side of the webpage, clicking “Input 6” (or “Input 7/8/9”), it displays the interface where users can configure the IP input parameters separately. (Figure-5)




Figure-5

**Parameters → CI Card:**

SFT358X supports 4 CI cards (Card A, B, C and D) to descramble programs from encrypted RF, ASI or IP. Users can click and enter 'CI Card' to configure the 2 cards respectively. (Figure-6)





Figure-6

**➤ CI Max Bit rate**


CI Max Bitrate options range from 48-108Mbps. Select a value in the pull-down list as principle: Actual Input Bitrate ≤ Max Bitrate ≤ CI Max decrypting capacity.

**NOTE!****➤ Input TS Mode**

SFT358X has 9 signal sources: Tuner 1-4, ASI, and IP 1-4. One CI card can applied to descramble one channel input signal from the 9 signal sources. 'Skip CI card' means to skip the card which is used for FTA stream.

**NOTE:** Card A & B are designed to descramble tuner 1 & 2, ASI input and IP input 1

to 4, while card C & D A are designed to descramble tuner 3 & 4, ASI input and IP input 1 to 4.



### ➤ Card Error Check

Users can decide whether to enable or disable the card error check function by checking the box.



After configuring the above CI card parameters, click **Apply** button to apply the input data and then click **Search program** button to parse programs from the channel selected in 'Input TS Mode'.

The searched out programs will be listed in the 'Descramble' box below: (Figure 7)





Figure-7

Check the program(s) to be descrambled and click **Set descramble** button to start descrambling the checked program(s). The program quantity to be descrambled will depend on the CAM/CI performance you apply to.



### Parameters → Biss:

From the menu on left side of the webpage, clicking “BISS”, it displays the interface where users can configure 4 BISS and descramble the input channels. (Figure-8)




Figure-8

### ➤ Input TS Mode


SFT358X has 9 signal sources: Tuner 1-4, ASI, and IP 1-4. One BISS tag can be applied to descramble one channel input signal from the 9 signal sources. ‘Skip BISS’ means not to involve BISS function and it is used for FTA stream.



**NOTE:** BISS A & B are designed to descramble tuner 1 & 2, ASI input and IP input,



while BISS C & D A are designed to descramble tuner 3 & 4, ASI input and IP input.



Items showing below are working as per the keys or codes set in the BISS scrambling side (DVB-S/S2 modulators).

Descrambler Key(0x):	.....
SK(0x):	.....
Word Mode:	Mode-E ▼
Burned Key:	<input type="checkbox"/>

Input corresponding items and data to active the BISS descrambling as principles be

Modulating Side (BISS SCR)	Receiving Side (BISS DESCR)	Digit (0x----)
Mode 1+SW Data	Mode 1+Descrambler Key	12
Mode E+ESW Data + Device	Mode E + Descrambler Key + Burned Key	16
Mode E+ESW Data + Input ID	Mode E + Descrambler Key + SK	14

After configuring the above BISS parameters, click **Apply** button to apply the input data and then click **Search program** button to parse programs from the channel selected in 'Input TS Mode'.

The searched out programs will be listed in the 'Descramble' box below: (Figure 9)





Figure-9

Check the program(s) to be descrambled with “√” and click **Set descramble** button to start descrambling the checked program(s). The program quantity to be descrambled will depend



on the CAM/CI performance you apply to.




Number before slash indicates the programs which have been descrambled.  
Number behind slash indicates the whole programs from the selected channel.

Users can also read the program information by clicking '+' symbol.

### Parameters → TS Config:

From the menu on left side of the webpage, clicking “TS Config”, it displays the interface where users can configure the parameters of TS output through ASI port groups. (Figure-8)



Configure TS ID and ON ID here for the output stream.

Figure-8

**ASI X out select:** SFT358X is equipped with 4 pairs of ASI out ports. Each pair can transfer one channel of **tuner** or one channel of **IP** content of corresponding channel. For instance, user can select content from “tuner 1” or “IP 1” to output through “ASI 1”.



**ASI X out bit-rate:** Users can set TS output bit rate for the corresponding channel.

After finishing the configuration, click **Apply** to confirm.

### Parameters → Mux:

From the menu on left side of the webpage, clicking “SPTS Select”, it displays the interface where users can configure the programs to be multiplexed. (Figure-9)

**NOTE:** Programs selected to multiplex can only output through the 48 SPTS.




Figure-9

Configure ‘Input Area’ and ‘Output Area’ with buttons in ‘Operation Area’. Instructions are as below:

☒ **PID Remap:** To enable/disable the PID remapping

**Refresh Input** To refresh the input program information

**Refresh Output** To refresh the output program information

**===>** Select one input program first and click this button to transfer the selected program to the right box to output.

- Similarly, user can cancel the multiplexed programs from the right box.
- To select all the input programs
- To select all the output programs
- To parse programs  time limitation of parsing input programs

### ◆ Program Modification:

The multiplexed program information can be modified by clicking the program in the 'output' area. For example, when clicking  , it triggers a dialog box (Figure 10) where users can input new information.




Figure-10

Input new data and click 'Save' button at last to confirm the modification.

### Parameters → IP Stream:

This unit supports TS output in IP (48 SPTS). Click "IP Stream" and it displays the interface where users can configure the SPTS out parameters. (Figure-13)




Figure-13

**Parameters → Network:**

From the menu on left side of the webpage, clicking “Network”, it will display the screen as Figure-14 where to configure the network parameters for the device.




Figure-14

**System → LCD/Keyboard:**

From the menu on left side of the webpage, clicking “LCD/Keyboard”, it will display the screen as Figure-15 where to control the device’s front panel.




Figure-15

**System → Password:**

From the menu on left side of the webpage, clicking “Password”, it will display the screen as Figure-16 where to set the login account and password for the web NMS.




Figure-16

**System → Save/Restore:**

From the menu on left side of the webpage, clicking “Save/Restore”, it will display the screen as Figure-17 where to save or restore your configurations.




Figure-17

**System → Backup/Load:**

From the menu on left side of the webpage, clicking “Backup/Load”, it will display the screen as Figure-18 where to backup or load your configurations.






Figure-18

**System → Firmware:**

From the menu on left side of the webpage, clicking “Firmware”, it will display the screen as Figure-19 where to update firmware for the device.






Figure-19

**System → Reboot:**

From the menu on left side of the webpage, clicking “Reboot”, it will display the screen as Figure-20 where to restart the device manually.




Figure-20

## Chapter 5 Troubleshooting

SOFTEL's ISO9001 quality assurance system has been approved by CQC organization. For guarantee the products' quality, reliability and stability. All SOFTEL products have been passed the testing and inspection before ship out factory. The testing and inspection scheme already covers all the Optical, Electronic and Mechanical criteria which have been published by SOFTEL. To prevent potential hazard, please strictly follow the operation conditions.

### Prevention Measure

- Installing the device at the place in which environment temperature between 0 to 45 °C
- Making sure good ventilation for the heat-sink on the rear panel and other heat-sink bores if necessary
- Checking the input AC voltage within the power supply working range and the connection is correct before switching on device
- Checking the RF output level varies within tolerant range if it is necessary
- Checking all signal cables have been properly connected
- Frequently switching on/off device is prohibited; the interval between every switching on/off must greater than 10 seconds.

### Conditions need to unplug power cord

- Power cord or socket damaged.
- Any liquid flowed into device.
- Any stuff causes circuit short
- Device in damp environment
- Device was suffered from physical damage
- Longtime idle.
- After switching on and restoring to factory setting, device still cannot work properly.
- Maintenance needed

## Chapter 6 Packing List

- |                      |      |
|----------------------|------|
| ● SFT358X 4 in 1 IRD | 1pcs |
| ● User's Manual      | 1pcs |
| ● RF Cables          | 2pcs |
| ● Power Cord         | 1pcs |

### Ordering Guide

SFT358X, 'X' should be interpreted as different digits which indicate tuners of different standard.

- ✓ SFT3581 DVB-C IRD
- ✓ SFT3584 DVB-T/T2 IRD
- ✓ SFT3585 DVB-S/S2 IRD